

UNIVERGE[®] SV9100

License Manager Server User Guide

NEC Corporation reserves the right to change the specifications, functions, or features at any time without notice.

NEC Corporation has prepared this document for use by its employees and customers. The information contained herein is the property of NEC Corporation and shall not be reproduced without prior written approval of NEC Corporation.

UNIVERGE is a trademark of NEC Corporation of America. Windows and Internet Explorer are registered trademarks of Microsoft Corporation.

Copyright 2015

**NEC Corporation of America
6535 N. State Highway 161
Irving, TX 75039-2402**

Communications Technology Group

TABLE OF CONTENTS

Chapter 1 Understanding License Manager

Section 1	Introduction	1-1
Section 2	System Version Licenses	1-1
Section 3	60 Day Trial	1-1
Section 4	SV9100 RESOURCE LIC-01 (System Port Licenses)	1-2
Section 5	User Client Licenses	1-2
	5.1 SV9100 STANDARD USER LIC-01 (Standard User Client License) ...	1-4
	5.2 SV9100 PREMIUM USER LIC-01 (Premium User Client License)	1-5
	5.3 Voice Mail Licensing	1-6
Section 6	IP Related License Comparison	1-7
	6.1 SV9100 IP Trunk LIC-01 (SIP/H.323)	1-7
	6.2 SV9100 Networking LIC-01 (K-CCIS)	1-8
	6.3 SV9100 NetLink Node LIC-01	1-8
Section 7	License Feature Codes	1-9

Chapter 2 Installing and Activating Licenses

Section 1	Installing a License	2-1
	1.1 Using PCPro	2-1
	1.2 Using WebPro	2-5
	1.3 Using a USB Drive	2-9



LIST OF FIGURES AND TABLES

Table 1-1	User Client License Feature Comparison Chart	1-3
Table 1-2	Standard User Client Licenses	1-4
Table 1-3	Premium User Client Licenses	1-5
Table 1-4	Voice Mail Licensing	1-6
Table 1-5	IP Related License Feature Comparison Chart	1-7
Table 1-6	IP Trunk (SIP/H.323) Licenses	1-7
Table 1-7	Networking (K-CCIS) Licenses	1-8
Table 1-8	NetLink Node Licenses	1-8
Table 1-9	License Information	1-9
Figure 2-1	PC Pro Ribbon Bar - Feature Activation	2-1
Figure 2-2	PCPro - Feature Activation Hardware Code	2-2
Figure 2-3	PCPro - Feature Activation Open License File	2-3
Figure 2-4	PCPro - Feature Activation Successful Registration Confirmation	2-3
Figure 2-5	PCPro - Feature Activation Off	2-4
Figure 2-6	WebPro Home Page - Feature Activation	2-5
Figure 2-7	WebPro - Feature Activation License Registration Page	2-6
Figure 2-8	WebPro - Feature Activation Open File to Upload	2-7
Figure 2-9	WebPro - Feature Activation OK to Proceed	2-8
Figure 2-10	WebPro - License Activation License Registered Successfully Confirmation	2-8



Understanding License Manager

Chapter 1

SECTION 1 INTRODUCTION

This manual is intended to give an overview on how the licensing procedure operates on the SV9100 platform. Some features and hardware require an appropriate license to be installed on a SV9100 processor to work. Each SV9100 CPU has a unique Hardware Key that is generated by NEC. Software Key Codes can be downloaded from the License Manager Server (LMS) and assigned to a hardware key.

The LMS is a web portal that allows users to login and download a license that can be installed on a CPU. The procedure involves logging the hardware key on to the LMS and then assigning a software key to the hardware key. After this is done, a license file can be downloaded and installed on a CPU using PC Pro, Web Pro or a USB drive.

SECTION 2 SYSTEM VERSION LICENSES

A system Version license is required for the system to be operational. When new versions are released, you can upgrade system to that version. However, the features that are released with that version require a license to activate.



NOTE

The latest version licenses include the previous version's licenses.

SECTION 3 60 DAY TRIAL

A 60 day trial license is only used when it is not possible to install a system license, which would have been downloaded from LMS. When the trial license expires, the SV9100 still operates, but only with features that are unlicensed. By default the trial is turned **Off** and can be turned on or off using PC Pro, Web Pro or telephone programming. Set Program 90-55-01 to enable (1) or disable (0) the trial.

The 60 day trial, with limited exception, gives full access to all features for its duration.



NOTE

The Encryption feature is not available with the 60 Day License.

The rules for the trial are listed below:

- The 60 day trial (demo) starts when the system is powered on. The option to enable or disable this feature is available in Data Program 90-55-01 (1=Enable and 0=Disable).
- When the CPU is powered down and left off, the timer stops and starts counting again when it is powered on.
- To determine the number of days left for the trial, set Program 90-55-01 to 1 and check Program 10-52-01.
- If a license has not been installed on the SV9100 and the trial license is turned on and then off, the days remaining continues to decrease.



When the SV9100 system is powered on, the 60 day trial starts and counts down 60 contiguous days. Disabling Program 90-55-01 does not deter the countdown progress.

SECTION 4 SV9100 RESOURCE LIC-01 (SYSTEM PORT LICENSES)

The SV9100 RESOURCE LIC-01 is required for each port. As an example, if you order a blade that has eight ports, you need eight SV9100 RESOURCE LIC-01 licenses. If you purchase SIP trunks, you need one SV9100 RESOURCE LIC-01 license for each trunk.

SECTION 5 USER CLIENT LICENSES

There are two user client licenses that are offered: Standard and Premium. When considering your customer's needs, [Table 1-1 User Client License Feature Comparison Chart](#) can be used to compare the features that are available.



When upgrading from Standard to Premium, there is an upgrade charge.

Table 1-1 User Client License Feature Comparison Chart

Category	Item	Standard	Premium
IP Client	SV9100 IP RESOURCE LIC-01 (5103) ➔ This should not be confused with SV9100 RESOURCE LIC-01 (0300).	√	√
	SV9100 IP CLIENT LIC-01 (5111)	√	√
Mobility	SV9100 MOBILE EXT LIC-01 (5201)	√	√
InMail	SV9100 INMAIL VM BOX LIC-01 (1012)	√	√
	SV9100 INMAIL EMAIL CLIENT LIC-01 (1014)	√	√
UM8000	SV91/93 UM8000 UMS CLIENT LIC-01 (1404)	√	√
UC Suite	SV9100 UCS CLIENT LIC-01 (5305) ➔ Includes Microsoft Outlook Integration.	√	√
	SV9100 UCS WEB CLIENT LIC-01 (5313)	√	√
	SV9100 UCS VOICEMAIL INT LIC-01 (5312)	√	√
	SV9100 UCS ADVANCED SERVICE LIC-01 (5309)	√	√
	SV9100 UCS ATTENDANT CLIENT LIC-01 (5304)	N/A	√
	SV9100 UCS CRM INTEGRATION LIC-01 (5310)	N/A	√
Contact Center	SV9100 CONTACT CENTER AGENT LIC-01 (2002)	N/A	√
	SV9100 CONTACT CENTER MIS AGENT LIC-01 (2104)	N/A	√

5.1 SV9100 STANDARD USER LIC-01 (Standard User Client License)

This is the entry level user license.

The Standard User License provides the following feature activation codes. Additional hardware may be required.

Table 1-2 Standard User Client Licenses

Feature Code	Item Name	Feature Name (WebPro/PCPro)
1012	SV9100 INMAIL VM BOX LIC-01	VM Box Users
1014	SV9100 INMAIL EMAIL CLIENT LIC-01	InMail Email Client
1404	SV91/93 UM8000 UMS CLIENT LIC-01	UMS Client (View Apps)
5111	SV9100 IP CLIENT LIC-01	IP Terminal (SIP-SLT/3rd Pty)
5103	SV9100 IP RESOURCE LIC-01	VoIP CH
5201	SV9100 MOBILE EXT LIC-01	Mobile Extension
5305	SV9100 UCS CLIENT LIC-01	Desktop Client
5309	SV9100 UCS ADVANCED SERVICE LIC-01	UCS Enhancement I
5312	SV9100 UCS VOICEMAIL INT LIC-01	UCS InMail Integration
5313	SV9100 UCS WEB CLIENT LIC-01	UCS Web Client

5.2 SV9100 PREMIUM USER LIC-01 (Premium User Client License)

This is the premium level user license.

The Premium User License provides the following feature activation codes. Additional hardware may be required.

Table 1-3 Premium User Client Licenses

Feature Code	Item Name	Feature Name (WebPro/PCPro)
1012	SV9100 INMAIL VM BOX LIC-01	VM Box Users
1014	SV9100 INMAIL EMAIL CLIENT LIC-01	InMail Email Client
1404	SV91/93 UM8000 UMS CLIENT LIC-01	UMS Client (View Apps)
2002	SV9100 CONTACT CENTER AGENT LIC 01	Contact Center Agent
2104	SV9100 CONTACT CENTER MIS AGENT LIC-01	ACD-MIS Agent
5103	SV9100 IP RESOURCE LIC-01	VoIP CH
5111	SV9100 IP CLIENT LIC-01	IP Terminal (SIP-SLT/3rd Pty)
5201	SV9100 MOBILE EXT LIC-01	Mobile Extension
5304	SV9100 UCS ATTENDANT CLIENT LIC-01	UCS Attendant Client
5305	SV9100 UCS CLIENT LIC-01	Desktop Client
5309	SV9100 UCS ADVANCED SERVICE LIC-01	UCS Enhancement I
5312	SV9100 UCS VOICEMAIL INT LIC-01	UCS InMail Integration
5313	SV9100 UCS WEB CLIENT LIC-01	UCS Web Client
5310	SV9100 UCS CRM INTEGRATION LIC-01	UCS CRM Integration

5.3 Voice Mail Licensing

The InMail and UM8000 voice mails require licensing to activate each mailbox and enable email forwarding capabilities. Each extension that needs a mailbox requires one of the licenses described in [Table 1-4 Voice Mail Licensing](#). These licenses are included in both the Standard and Premium user licenses and can be purchased separately.

For the ability to forward voice mails to an email server on InMail, a separate license (1014) is required for each mailbox that uses this feature. The UM8000 standard mailbox license (1404) includes the ability to forward voice mails to an email server.

Table 1-4 Voice Mail Licensing

Feature Code	Item Name	Feature Name (WebPro/PCPro)	Description
1012	SV9100 INMAIL VM BOX LIC-01	VM Box Users	Enables standard InMail mailbox features. Licenses are consumed as mailboxes are enabled in PRG 47-02-01.
1014	SV9100 INMAIL EMAIL CLIENT LIC-01	InMail Email Client	Enables email forwarding on InMail. Licenses are consumed as the email forwarding option is enabled in PRG 47-02-20.
1404	SV91/93 UM8000 UMS CLIENT LIC-01	UMS Client (View Apps)	Enables standard mailbox features and email forwarding on UM8000 Mail. Licenses are consumed as mailboxes are created in the UM8000 Web Admin Console.

SECTION 6 IP RELATED LICENSE COMPARISON

There are three IP related licenses: IP Trunk (SIP/H.323), IP Networking (CCIS) and NetLink. When considering your customer’s needs, [Table 1-5 IP Related License Feature Comparison Chart](#) can be used to compare the features that are available with each license.

Table 1-5 IP Related License Feature Comparison Chart

Item	IP Trunk (SIP/H.323)	IP Networking (CCIS)	NetLink
SV9100 IP RESOURCE LIC-01 (5103) ➡ This should not be confused with SV9100 RESOURCE LIC -01 (0300).	√	√	√ (x 32)
SV9100 IP TRUNK LIC-01 (5001)	√	N/A	N/A
SV9100 NETWORKING LIC-01 (5012)	N/A	√	N/A
SV9100 NETLINK NODE LIC-01 (0002)	N/A	N/A	√

6.1 SV9100 IP Trunk LIC-01 (SIP/H.323)

This license includes IP trunk licenses for SIP and H.323.

The IP Trunk License provides the following feature activation codes. Additional hardware may be required.

Table 1-6 IP Trunk (SIP/H.323) Licenses

Feature Code	Item Name	Feature Name (WebPro/PCPro)
5001	SV9100 IP TRUNK LIC-01	IP Trunk (SIP/H323)
5103	SV9100 IP RESOURCE LIC-01	VoIP CH

6.2 SV9100 Networking LIC-01 (K-CCIS)

This license includes IP trunk licenses for K-CCIS over IP.

The Networking License provides the following feature activation codes. Additional hardware may be required.

Table 1-7 Networking (K-CCIS) Licenses

Feature Code	Item Name	Feature Name (WebPro/PCPro)
5012	SV9100 NETWORKING LIC-01	K-CCIS over IP
5103	SV9100 IP RESOURCE LIC-01	VoIP CH

6.3 SV9100 NetLink Node LIC-01

This license includes licenses for NetLink.

The NetLink License provides the following feature activation codes. Additional hardware may be required.

Table 1-8 NetLink Node Licenses

Feature Code	Item Name	Feature Name (WebPro/PCPro)
0002	SV9100 NETLINK NODE LIC-01	NetLink
5103	SV9100 IP RESOURCE LIC-01	VoIP CH (x 32)

SECTION 7 LICENSE FEATURE CODES

Table 1-9 License Information lists all feature license codes.

Table 1-9 License Information

Feature Code	Item Name	Feature Name (WebPro/PCPro)	Min	Max	Note
0002	SV9100 NETLINK NODE LIC-01	NetLink	1	49	This license number is determined according to number of secondary sites. For example, if you have one (1) Primary and three (3) Secondary sites networked; three (3) licenses are needed. All licenses are activated at the Primary site. With each "SV9100 NETLINK NODE LIC-01" you receive (32) "SV9100 IP RESOURCE- LIC 01" licenses.
0007	SV9100 HM LIC	Hotel/Motel	On/Off		–
0017	SV9100 REMOVE LIC		On/Off		–
0030	SV9100 ENCRYPTION LIC	Encryption	On/Off		–
0031	SV9100 NAT TRAVERSAL LIC	NAT Traversal	On/Off		–
0041	SV9100 XMLPRO LIC	XML Pro	On/Off		–
0042	SV9100 VIDEO MCU LIC	Video MCU	On/Off		–
0046	SV9100 PMS LIC	PMS	On/Off		–
0047	SV9100 REMOTE CONF LIC-01	Remote Conference	1	20	–
0048	SV9100 HW MIGRATION LIC	H/W migration	On/Off		–
0111	SV9100 1ST PARTY CTI LIC-01	1st Party CTI (Ethernet)	1	256	1st Party CTI (Ethernet) xx client
0112	SV9100 3RD PARTY CTI-LIC 01	3rd Party CTI Client	0	999	–
0123	SV9100 OAI LIC	OAI Interface	On/Off		–
0300	SV9100 RESOURCE - LIC 01	System Port	1	1296	Required for each port TDM/IP station port, trunk port, etc., that connects to the system.
0411	SV9100 VERSION LIC (R1)	Version R1	On/Off		–
0413	SV9100 VERSION LIC (R3)	Version R3	On/Off		–
1001	SV9100 INMAIL VRS PORT-LIC 01	VRS Port	1	16	–
1012	SV9100 INMAIL VM BOX-LIC 01	VM Box	1	896	–
1014	SV9100 INMAIL EMAIL CLIENT-LIC 01	InMail Email Client	1	896	–
1402	SV91/93 UM8000 FAX PORT-LIC 01	UMS FAX Port	1	4	1 Port FAX
1403	SV91/93 UM8000 TTS PORT-LIC 01	UMS TTS Port	1	6	1 Port of Text-to-Speech language for Microsoft outlook activation license.

Table 1-9 License Information (Continued)

Feature Code	Item Name	Feature Name (WebPro/PCPro)	Min	Max	Note
1404	SV91/93 UM8000 UMS CLIENT-LIC 01	UMS Client	1	896	This license provides the following for UM8000 Mail: – One Subscriber or Guest Mailbox. – One View App Session, (Supports View Mail, View Call Plus, VMM (Outlook), VML (Lotus Notes), VMG (GroupWise) and Web Mailbox clients Manager.)
1406	SV91/93 UM8000 SYSTEM LANG-01 LIC	UMS Multi-Language	1	25	1 Language activation License.
1407	SV91/93 UM8000 HOSPITALITY & PMS LIC	UMS Hospitality and PMS	On/Off		Hospitality and PMS activation license.
1408	SV91/93 UM8000 HOSPITALITY LANG-LIC 01	UMS Hospitality Language	1	10	1 Hospitality Language activation license.
1409	SV91/93 UM8000 AMIS NETWORK LIC	UMS Amis/Plus Net	On/Off		–
1410	SV91/93 UM8000 TTS LANG-LIC 01	UMS TTS Language	1	10	1 Port of Text-to-Speech language activation license.
2002	SV9100 CONTACT CENTER AGENT-LIC 01	ACD Client	1	896	–
2101	SV9100 CONTACT CENTER P-EVENT LIC	ACD P-event	On/Off		–
2102	SV9100 CONTACT CENTER-MIS LIC	ACD-MIS Basic	On/Off		–
2103	SV9100 CONTACT CENTER RT-REPORTING-LIC 01	ACD-MIS Monitor	1	16	–
2104	SV9100 CONTACT CENTER MIS AGENT-LIC 01	ACD-MIS Agent	1	197	–
2105	SV9100 CONTACT CENTER SKILL/CID BASE LIC	ACD Advance	On/Off		–
3000	SV91/93/95 CA STATION PKG LIC-20	CA-Basic	On/Off		–
3001	SV91/93/95 CA STATION PKG LIC-256	CA-256 Station	On/Off		–
3002	SV91/93/95 CA UPG LIC-20/256	CA-Up 20 to 256	On/Off		–
3003	SV91/93/95 CA NETWORK CLIENT PACK-LIC 05	CA-Network Client	1	999	–
3004	SV91/93/95 CA ADD REMOTE SITE-LIC 01	CA-Add Remote Site	1	999	–
3005	SV91/93/95 CA ADD REMOTE SOFTWARE-LIC 01	CA-Remote Site Soft	1	999	–
3006	SV91/93/95 CA SYS TRAFFIC ANALYSIS LIC	CA-Traffic Analys	On/Off		–
3007	SV91/93/95 CA SYS PMS INTEGRATION LIC	CA-PMS Integratio	On/Off		–

Table 1-9 License Information (Continued)

Feature Code	Item Name	Feature Name (WebPro/PCPro)	Min	Max	Note
3008	SV91/93/95 CA WEB REPORTING-LIC 05	CA-Web Reporting	On/Off		–
3013	SV91/93/95 CA ADDITIONAL STATION LIC-256	CA-Add Stations	1	256	–
3014	SV9100 CA E911-REPORTING-LIC	CA-E911 Reporting	1	999	–
3200	SV91/93 IP RECORDER - Basic Package	IP REC BASIC PAC	On/Off		–
3201	SV91/93 IP RECORDER - Basic Supervisor Capacity	REC BASIC SUPV	1	256	–
3202	SV91/93 IP RECORDER - Basic Port Capacity	REC BASIC PORT	1	256	–
3203	SV91/93 IP RECORDER - IP Recorder-LIC 01	IP REC ADD 256	1	256	
3204	SV91/93 IP RECORDER - Call Scoring-LIC 01	IP REC CALLSCORING	1	999	
3205	SV91/93 IP RECORDER - Reporting-LIC	IP CALL REPORTING	On/Off		
3210	SV91/93/95 IP/DIGITAL-REPORT-LIC 01	VSR-IP Port			Includes feature codes 3210 and 3211.
3211	SV91/93/95 IP/DIGITAL-ENCRYPTION-LIC 01	VSR-Encrypt			–
3212	SV91/93/95 MANAGER PORT-LIC 01	VSR-Manager			–
3213	SV91/93/95 IP/DIGITAL-REPORT-LIC 01	VSR-Reporter			–
3214	SV91/93/95 IP/DIGITAL ARCHIVER PORT-LIC 01	VSR-Archive			–
3300	SV91/93 E911 ESN Suite-LIC	ESN Registry	On/Off		–
3301	SV91/93 E911On-Site Monitor-LIC	ESN Site Monitor	1	9999	–
3302	SV91/93 E911 ALARM CLIENT ADD-ON -LIC	ESN Alarm Client	1	9999	–
3303	SV91/93 E911 Call Notify-Addon-LIC	ESN Call Notify	1	9999	–
3400	SV9100 CTI OCX LIC	CTI-OCX	On/Off		–
5001	SV9100 IP TRUNK-LIC 01	IP Trunk	1	400	–
5012	SV9100 NETWORKING-LIC 01	K-CCIS over IP	1	400	Each system need this license to specify suitable K-CCIS over IP channel (Trunk) number.
5091	SV9100 NETWORKING OVER IP-LIC 01	Networking over IP	1	128	

Table 1-9 License Information (Continued)

Feature Code	Item Name	Feature Name (WebPro/PCPro)	Min	Max	Note
5103	SV9100 IP RESOURCE-LIC 01	VoIP Channel	1	12800	–
5111	SV9100 IP PHONE-LIC 01	IP Terminal	1	896	–
5201	SV9100 MOBILE EXT-LIC 01	Mobile Extension	1	896	–
5301	SV9100 UCS SOFTPHONE CLIENT-LIC01	UCS SoftPhone Client	1	256	–
5303	SV9100 UCS SOFTPHONE E CLIENT-LIC01	UCS SoftPhone Enhance	1	256	–
5304	SV9100 UCS ATTENDANT CLIENT-LIC 01	UCS Attendant Client	1	512	–
5305	SV9100 UCS CLIENT-LIC01	UCS Client	1	256	–
5309	SV9100 UCS ADVANCED SERVICE-LIC 01	UCS Enhancement I	1	512	–
5310	SV9100 UCS CRM INTEGRATION-LIC 01	UCS CRM Integration	1	256	This will support external CRM applications. Refer to the UC Suite Installation manual for further details.
5311	SV9100 MOBILE PRESENCE LIC	UCS Mobile Presence	On/Off		–
5312	SV9100 UCS VOICEMAIL INT-LIC 01	UCS InMail Integration	1	128	Access to InMail function from UC Suite. Client base license.
5313	SV9100 UCS WEB CLIENT-LIC 01	UCS Web Client	1	512	–
5320	SV9100 UCS VERSION LIC(R1)	UCS Version 1	On/Off		–
6200	PVA-CCIS PORT LIC	PVA-CCIS Port	4	400	–
6201	SV9100 PVA-PMS US LIC	PVA-PMS	On/Off		–
6300	RGA CONF PORT-LIC 08	RGA Conference	8	32	–
6301	RGA CONF ENH I-LIC	RGA-CNF ENH I	On/Off		
6302	RGA CONF ENH II-LIC	RGA-CNF ENH II	On/Off		
6303	RGA CONF ENH III-LIC	RGA-CNF ENH III	On/Off		
6304	RGA CONF MULTI LANG-LIC 01	RGA-CNF Multi Lang	1	60	

Installing and Activating Licenses

Chapter 2

SECTION 1 INSTALLING A LICENSE

Once a license file is received by the installer the license file must be loaded onto the SV9100. The license file can be loaded in three different ways using PCPro, Web Pro or a USB drive.


If the 60 day trial license is running, it should be turned off once a system license has been installed, If a system license was installed and the trial was left on, the trial remains active and continues to countdown. To turn off the trial license, set Program 90-55-01 to **0** using PCPro, Web Pro or a USB drive.

1.1 Using PCPro

To install a license using PCPro:

1. Connect to the SV9100 system using PCPro and click **Feature activation**.


Figure 2-1 PC Pro Ribbon Bar - Feature Activation



- 2. When the trial license is running, the Feature Activation screen shows all features in the **Status** column as On. The **Expires** column shows Unlimited. This does not mean that the license never expires, the expiration date should be checked in Program 10-52-01 in PCPro, Web Pro or telephone programming.


Click **Load File** on the Feature Activation screen.

Figure 2-2 PCPro - Feature Activation Hardware Code




3. On the Open screen, browse to the license file and click **Open**.

Figure 2-3 PCPro - Feature Activation Open License File




4. The license is installed. When the Activation Success screen appears, click **OK**.

Figure 2-4 PCPro - Feature Activation Successful Registration Confirmation



If the trial license is running, change Program 90-55-01 from a 1 to a 0 and exit programming.

Figure 2-5 PCPro - Feature Activation Off




1.2 Using WebPro

To install a license using WebPro:

1. Login to WebPro. From the home page, click the **Feature Activation** icon .

Figure 2-6 WebPro Home Page - Feature Activation



- When the Feature Activation screen opens, scroll to the bottom of the page and click the **Browse** button.

Figure 2-7 WebPro - Feature Activation License Registration Page

License Registration

Hardware Key Code:

The following features are registered:


Feature No		Feature Name	License Qty	Expiry Date
0007	Basic Feature	Hotel/Motel	1	Never
0031		NAT traversal	1	Never
0042		Video MCU	1	Never
0046		PMS	1	Never
0047		Remote Conference	21	Never
0048		H/W migration	2	Never
0300		System Port	375	Never
0411		Version R1	1	Never
1001	VM Related	VRS Port	16	Never
1012		VM Box	2	Never
1014		InMail Email Client	8	Never
1401		UMS Port	8	Never
1402		UMS Fax Port	2	Never
1404		UMS Client	15	Never
1406		UMS Multi Language	1	Never
5001	Terminal Related	IP Trunk	8	Never
5103		VoIP Channel	260	Never
5111		IP Terminal	34	Never
5201		Mobile extension	9	Never
5305		UCS Client	5	Never
5309		UCS Enhancement 1	5	Never
5312		UCS InMail Integration	5	Never
5313		UCS Web Client	5	Never
6000	In Skin Application	PVA-CONF Port	8	Never
6004		PVA-CONF Enhancement	1	Never

Upload a license file to the KTS:

Demo License


3. On the Choose File to Upload screen, locate the license file and click **Open**.

Figure 2-8 WebPro - Feature Activation Open File to Upload



- The path to the file displays. Click the **Upload** button, then click **OK** to install the license.

Figure 2-9 WebPro - Feature Activation OK to Proceed



- After WebPro installs the license, **License registered successfully** displays.

Figure 2-10 WebPro - License Activation License Registered Successfully Confirmation

License Registration

Hardware Key Code: 341000832131

The following features are registered:

Feature No	Basic Feature	Feature Name	License Qty	Expiry Date
0007		Hotel/Motel	1	Never
0031		NAT traversal	1	Never
0042		Video MCU	1	Never
0046		PMS	1	Never
0047		Remote Conference	21	Never
0048		H/W migration	2	Never
0300		System Port	375	Never
0411		Version R1	1	Never
1001	VM Related	VRS Port	16	Never
1012		VM Box	2	Never
1014		InMail Email Client	8	Never
1401		UMS Port	8	Never
1402		UMS Fax Port	2	Never
1404		UMS Client	15	Never
1406		UMS Multi Language	1	Never
5001	Terminal Related	IP Trunk	8	Never
5103		VoIP Channel	260	Never
5111		IP Terminal	34	Never
5201		Mobile extension	9	Never
5305		UCS Client	5	Never
5309		UCS Enhancement 1	5	Never
5312		UCS InMail Integration	5	Never
5313		UCS Web Client	5	Never
6000	In Skin Application	PVA-CONF Port	8	Never
6004		PVA-CONF Enhancement	1	Never

Refresh Home

License registered successfully.

You can obtain your license file by one of two methods:

- Online at the NEC Product Activation server
- By using the Feature Activation dialog in PCPro

Note: Some features require a 2nd initialize of the system before they take effect.

If the trial license was running, set Program 90-55-01 to **0** and click the **Refresh** icon in the License Registration web page. Details of the installed license display.

1.3 Using a USB Drive

To install a license using a USB drive:

1. Copy the license files to the root of the USB drive.
2. Plug the USB drive into the USB port on the GCD-CP10 (CPU).
3. Access Program 10-49-01 and enter **1** to start reading in any licenses from the USB drive.

The SV9100 system reads the licenses on the CPU. If more than one file for the same system is detected on the USB drive, it reads them all.

If the system successfully reads the licenses, **Entry OK** is displayed on the handset.

If the trial license was running, set Program 90-55-01 to **0** to turn it off.

4. To view the installed licenses, connect to PCPro / WebPro.



***UNIVERGE*[®] SV9100**

License Manager Server User Guide